

Cirval

Installation and commissioning guide



WARNING This document is a guide for the installation and commissioning of Cirval regulator. It is compulsory to read the complete operation, maintenance and warning manual before working on the device. Full operation, maintenance and warning manual can be found on the PIETRO FIORENTINI S.P.A. website.

1.1 - GENERAL SAFETY WARNINGS

WARNING The equipment described in this manual is:

- a device subject to pressure in pressurized systems;
- normally included in systems transporting flammable gases (for example: natural gas).

WARNING If the gas used is a combustible gas, the area where the equipment is installed is called a “danger zone” because there are residual risks of the formation of potentially explosive atmospheres. In and around “danger zones” it is absolutely:

- necessary there are no effective ignition sources present;
- prohibited to smoke.

CAUTION Authorized operators shall not perform operations or interventions on their own initiative that are not within their competence. Never work on the equipment:

- Under the influence of exciting substances such as, for example, alcohol;
- In the case of using drugs that can lengthen reaction time.

NOTICE The employer must train and inform operators on how to behave during operations and what equipment to use.

Before installation, commissioning or maintenance, operators must:

- Take note of the safety regulations applicable to the installation site where they are to operate;
- Obtain, when required, the necessary authorizations to operate;
- Equip themselves with the necessary individual safeguards required in the procedures described in this manual;
- Ensure that the area in which they are to work is equipped with the required collective protections and necessary safety signs.

1.2 - GENERAL INFORMATION ABOUT CONNECTIONS

The equipment must be installed in the line with the arrow on the body facing in the direction of gas flow. The on-line installation must include:

Pos.	Description
1	no.1 shut-off valve upstream of the equipment.
2	no. 2 vent valves placed one upstream and one downstream of the equipment.
3	no. 2 pressure gauges placed one upstream and one downstream of the equipment.
4	no. 1 pressure regulator.
5	no. 1 shut-off valve downstream of the equipment.




Fig. 1.1. In-line Installation




Fig. 1.2. Square installation

NOTICE When the device is used in gas pressure reduction stations, it must be installed at least according to the requirements of UNI EN 12186:2014 or UNI EN 12279:2007. The vents of the equipment must be channeled according to UNI EN 12186: 2014 or UNI EN 12279: 2007 or the standards in force at the place of installation of the equipment.

All the equipments used in the commissioning procedures are shown in chapter 1.11.

1.3 - CIRVAL INSTALLATION PROCEDURES

Step	Operation
1	Place the equipment in the section of the line used for it.
2	Place gaskets between the line flanges and the regulator flanges.
3	Insert the bolts into the appropriate holes in the connecting flanges.
4	Screw the bolts following the technical rules for tightening the flanges.

NOTICE For installation carried out after maintenance, replace the gaskets.

1.4 - REGULATOR COMMISSIONING PROCEDURE

In the application consisting of multiple parallel pressure control lines, it is recommended to commission one line at a time starting with the one with the lowest set-point. The set-point value is recalled on the test certificate attached to each piece of equipment.

Step	Operation
1	Partially open the vent valve.
2	Very slowly open the upstream shut-off valve. NOTICE Check the pressure by referring to the pressure gauge located upstream.
3	Check the pressure of the line inlet pipe by referring to the upstream pressure gauge.
4	To adjust the regulator to the required set-point value, remove the spring cap and turn the adjustment nut: • clockwise to increase the pressure value; • counterclockwise to decrease the pressure value. NOTICE Check the pressure by referring to the pressure gauge located downstream.
5	Place and secure the spring cap.
6	Close the vent valve.
7	Check that the downstream pressure and make sure the regulator locks up and the pressure does not build.
8	Check with a foaming substance the tightness of all joints located between the shut-off valves.
9	Very slowly open the downstream shut-off valve until the pipeline is completely filled. NOTICE If the pressure of the downstream pipeline is lower than the set-point pressure, partialize the opening of the downstream shut-off valve so as not to exceed the value of the maximum flow rate of the system. Check the pressure by referring to the downstream pressure gauge.

1.5 - COMMISSIONING OF THE CIRVAL + IN LINE MONITOR OPERATION

Step	Operation
1	Remove the spring cap from the main regulator.
2	Remove the spring cap from the regulator in inline monitor function.
3	Partially open the vent valve.
4	Very slowly open the upstream shut-off valve, checking that the downstream pressure (Pd) indicated by the downstream pressure gauge (5) does not exceed the required setting value by more than 50%.
5	Check the pressure of the line inlet pipe by referring to the upstream pressure gauge.
6	Insert and tighten the Q key (chapter 1.11) in the slot of the cap to fully open the main regulator.
7	To adjust the in-line monitor regulator to the required set-point value turn the adjustment nut: • clockwise to increase the pressure value; • counterclockwise to decrease the pressure value. NOTICE Check the pressure by referring to the pressure gauge located downstream.
8	Close the vent valve.
9	Check that the downstream pressure and make sure the regulator locks up and the pressure does not build.
10	Partially open the vent valve.
11	Unscrew and remove the Q key (chapter 1.11) from the slot of the cap.
12	Check that the set-point pressure of the main regulator is at the set value by referring to the pressure value indicated by the downstream pressure gauge.
13	Verify that the regulator with inline monitor function is fully open (100%). NOTICE The monitor regulator is fully open, when the pressure indicated on the intermediate pressure gauge is the same as the upstream pressure gauge.
14	Close the vent valve.
15	Check that the downstream pressure and make sure the regulator locks up and the pressure does not build (refer to the nameplate SG value).
16	Install and tighten spring cap on the main regulator.
17	Install and tighten spring cap on the in-line monitor regulator.
18	Check with a foaming substance the tightness of all joints located between the shut-off valves.

Step	Operation
19	Slowly open downstream shut-off valve until the pipeline is completely filled. NOTICE If the pressure of the downstream pipeline is lower than the regulator set point pressure, partially open the downstream shut-off valve so as not to exceed the value of the maximum flow rate and pressure of the system. Check the pressure by referring to the downstream pressure gauge.

1.6 - COMMISSIONING OF THE REGULATOR + IFM BUILT-IN MONITOR

In the application consisting of multiple parallel pressure control lines, it is recommended to commission one line at a time starting with the one with the lowest set-point. The set-point value is recalled on the test certificate attached to each piece of equipment.

Step	Operation
1	Remove the spring cap from the main regulator.
2	Remove the spring cap from the built-in IFM monitor.
3	Partially open the vent valve.
4	Very slowly open the upstream shut-off valve, checking that the downstream pressure (Pd) indicated by the downstream pressure gauge does not exceed the required setting value by more than 50%.
5	Check the pressure of the line inlet pipe by referring to the upstream pressure gauge.
6	Insert and tighten the Q key (chapter 1.11) in the slot of the cap to fully open the main regulator.
7	To adjust the set point of the built-in IFM monitor turn the adjustment nut: • clockwise to increase the pressure value; • counterclockwise to decrease the pressure value. NOTICE Check the pressure by referring to the pressure gauge located downstream.
8	Close the vent valve.
9	Check that the downstream pressure and make sure the regulator locks up and the pressure does not build.
10	Partially open the vent valve.
11	Unscrew and remove the Q key (chapter 1.11) from the slot of the cap.
12	Check that the set-point pressure of the main regulator is at the preset value by referring to the pressure value indicated by the downstream pressure gauge.
13	Close the vent valve.
14	Check that the downstream pressure (Pd), after an increment phase, does not exceed the closing pressure value of the main regulator (refer to the nameplate SG value).
15	Insert the spring cap into the main regulator.
16	Insert the spring cap into the built-in IFM monitor.
17	Check with a leak foaming substance the tightness of all joints located between the shut-off valves.
18	Slowly open downstream shut-off valve until the pipeline is completely filled. NOTICE If the pressure of the downstream pipeline is lower than the set-point, partially open the downstream shut-off valve so as not to exceed the set-point of the maximum flow rate of the system. Check the pressure by referring to the downstream pressure gauge.

1.7 - COMMISSIONING OF THE REGULATOR + IMD BUILT-IN MONITOR

In the application consisting of several pressure control lines, it is recommended to commission one line at a time starting with the one with the lowest set-point. The set-point value is recalled on the test certificate attached to each piece of equipment.

Step	Operation
1	Remove the spring cap from the main regulator.
2	Partially open the vent valve.
3	Very slowly open the upstream shut-off valve, checking that the downstream pressure (Pd) indicated by the downstream pressure gauge does not exceed the required setting value by more than 50%.
4	Check the pressure of the line inlet pipe by referring to the upstream pressure gauge.
5	Insert and tighten the Q key (chapter 1.11) in the slot of the cap to fully open the main regulator.
6	Check the set-point value of the built-in IMD monitor by referring to the downstream pressure gauge.
7	Check the controlled escape of gas from the vent valve. NOTICE Check with foaming solution.
8	Close the vent valve.
9	Check that the downstream pressure and make sure the regulator locks up and the pressure does not build.
10	Check the controlled escape of gas from the vent. NOTICE Check with foaming solution.
11	Partially open the vent valve.
12	Unscrew and remove the Q key (chapter 1.11) from the slot of the cap.

Step	Operation
13	Check that the set-point pressure of the main regulator is at the preset value by referring to the pressure value indicated by the downstream pressure gauge. NOTICE To adjust the regulator to the required set-point value turn the adjustment nut: • clockwise to increase the pressure value; • counterclockwise to decrease the pressure value.
14	Close the vent valve.
15	Check that there is no gas leakage from the vent. NOTICE Check with foaming solution.
16	Check that the downstream pressure and make sure the regulator locks up and the pressure does not build.
17	Check with a leak foaming substance the tightness of all joints located between the shut-off valves.
18	Slowly open downstream shut-off valve until the pipeline is completely filled. NOTICE • If the pressure of the downstream pipeline is lower than the set-point pressure, partially open the downstream shut-off valve so as not to exceed the set-point and the maximum flow rate of the system. • Check the pressure by referring to the downstream pressure gauge.

1.8 - COMMISSIONING OF THE CIRVAL REGULATOR + LA SLAM-SHUT VALVE

1.8.1 - CHECK FOR LEAKAGE OF THE LA SLAM-SHUT VALVE

Step	Operation
1	Check that the slam-shut valve is in the closed position.
2	Open the vent valve to completely drain the downstream section.
3	Slowly open the upstream shut-off valve.
4	Check for leakage of the slam-shut valve through the vent valve. NOTICE Check the vent for leaks with a foaming substance.

1.8.2 - COMMISSIONING OF CIRVAL REGULATOR + LA SLAM-SHUT VALVE

Step	Operation
1	Check that the vent valve is partially open.
2	Check that the LA slam-shut valve is in the closed position.
3	Partially open the upstream shut-off valve, checking the pressure value indicated by the upstream pressure gauge.
4	Perform the internal leakage test of the LA slam-shut valve, referring to Chapter 1.8.2.
5	Slowly pressurize the downstream line by resetting the knob counterclockwise to loosen the LA slam-shut valve, checking that the downstream pressure (Pd) indicated by the downstream pressure gauge does not exceed the required set-point value by more than 50%.
6	At the time the regulator goes into service, the pressure of the downstream pressure gauge will be equal to the set-point of the main regulator. NOTICE In the first pressurization phase of the line, the pressure of the downstream pressure gauge may exceed the required set-point value, depending on the response time of the regulator.
7	Fully open the upstream shut-off valve.
8	Check the pressure switch settings of the LA slam-shut valve by referring to Section 1.8.3.
9	If the downstream pressure (Pd) is not at the required set-point value, adjust the regulator as follows: • value of downstream pressure (Pd) less than the required set-point value: screw the set-point spring by turning the spring adjustment ring nut clockwise; • value of downstream pressure (Pd) higher than the required set-point value: unscrew the set-point spring by turning the spring adjustment ring nut counterclockwise.
10	Check the downstream pressure (Pd) by referring to the downstream pressure gauge.
11	Close the vent valve.
12	Check that the downstream pressure (Pd), after an increment phase, does not exceed the lock-up pressure value. NOTICE If the pressure in the section of pipeline between the regulator and the downstream shut-off valve exceeds the shut-off pressure value.
13	Check all connections between shut-off valves for tightness with a foaming substance.
14	In case external leakage is found, repair the leakage points and repeat the procedure from step 7.
15	Very slowly open the downstream shut-off valve until the pipeline is completely filled. NOTICE • If the pressure of the downstream pipeline is lower than the set-point pressure, partially open the downstream shut-off valve so as not to exceed the set-point value or the maximum flow rate of the system. • Check the pressure by referring to the downstream pressure gauge.

1.8.3 - ADJUSTMENT FOR LA SLAM-SHUT VALVE (LA-BP, LA-MP, LA-TR)

Adjustment of spring to trip for maximum pressure

Step	Operation
1	Increase the downstream pressure to the slam-shut valve's tripping set-point by connecting an external pressure source to the drain valve placed on the downstream pipeline. NOTICE Check the pressure by referring to the pressure gauge placed downstream of the main regulator. If the slam-shut valve: • trips before the expected pressure value: turn (clockwise) the adjusting nut so as to compress the spring more; • does not trip at the expected pressure value: turn (counterclockwise) the adjusting nut, so as to relieve the spring.
2	Decrease the pressure of the downstream section by opening the vent valve to bring it up to the set-point value of the main regulator.
3	Close the vent valve.
4	Arming the slam-shut valve by acting on the reset knob.
5	Repeat steps 2-3-4 at least three times. NOTICE The set-point value must comply with the operating limits indicated on the nameplate.
6	Disconnect the external pressure source from the vent valve.

Adjustment of spring for tripping by minimum pressure (optional)

Step	Operation
1	Partially open the vent valve in the atmosphere and keep it open for the next steps.
2	Turn the adjustment nut counterclockwise of the regulator to decrease the downstream pressure (Pd) to the minimum pressure required for the slam-shut valve to trip.
3	In case the required minimum pressure value is not reached by intervention of the minimum set-point, remove the adjustment ring nut, remove the adjustment spring and install the proper spring. NOTICE Check the value of the slam-shut valve tripping pressure indicated by the downstream pressure gauge.
4	If the slam-shut valve: • trips before the expected pressure value: turn (counterclockwise direction) the adjustment nut so as to unload the spring; • does not trip at the expected pressure value: turn (clockwise) the adjustment ring nut, so as to compress the spring more. After verifying that the slam-shut valve trips at the preset value, act as follows: 1. Close the air vent valve. 2. Position the adjustment spring, the end cap, adjusting screw. 3. Slowly open the upstream shut-off valve until the downstream pressure value (Pd) reaches the regulator's set value, referring to the downstream pressure gauge.
5	4. Close the upstream shut-off valve. 5. Slowly and partially open the air vent valve to decrease the downstream pressure by referring to the downstream pressure gauge until the minimum pressure trip value is reached. 6. Verify the correct set-point of the minimum spring by repeating steps 3-4-5 at least three times. 7. Perform set-point of the main regulator referring to par. 1.4.
6	Open the slam-shut valve by pulling down the reset knob and keep it open manually.
7	Turn the adjustment nut clockwise to increase the downstream pressure to the set value of the regulator.
8	Arming the slam-shut valve by pulling down the reset knob.
9	Close the vent valve.

1.9 - ADJUSTMENT OF THE CIRVAL REGULATOR WITH IN-LINE MONITOR FUNCTION + LA SLAM-SHUT VALVE

Step	Operation
1	Partially open the vent valve.
2	Remove the spring cap from the main regulator.
3	Remove the spring cap from the regulator with in-line monitor function.
4	Insert and tighten the Q key (chapter 1.11) in the slot of the cap to fully open the main regulator. Very slowly and partially open the inlet shut-off valve.
5	NOTICE Check the pressure by referring to the pressure gauge located upstream.
6	Perform the internal leakage test of the LA slam-shut valve, referring to Section 1.8.1.
7	Slowly pressurize the control line, pulling down the knob of the LA slam-shut valve, checking that the downstream pressure (Pd) indicated by the downstream pressure gauge does not exceed the required set-point value by more than 50%.
8	At the time the regulator enters into service, the pressure of the downstream pressure gauge will be equal to the set-point value of the monitor regulator
9	Fully open the upstream shut-off valve.
10	Check the setting of the LA slam-shut valve pressure switch by referring to Section 1.8.3.

Step	Operation
11	Pull the slam-shut valve reset stem outward until the LA slam-shut valve is engaged. NOTICE Check the set-point pressure of the worker regulator with in-line monitor function in the pressure gauge after inserting the plug into the regulator with in-line monitor function.
12	If the downstream pressure (Pd) is not at the required set-point value, adjust the inline monitor by: • value of downstream pressure (Pd) less than the required set-point value: screw the set-point spring by turning the adjustment spring nut clockwise; • value of downstream pressure (Pd) higher than the required set-point value: screw the set-point spring by turning the adjustment spring nut counterclockwise. NOTICE Check the pressure by referring to the pressure gauge located downstream.
13	Close the vent valve.
14	Check the lock-up pressure.
15	Partially open the vent valve.
16	Unscrew and remove the Q key (chapter 1.11) from the cap slot. Verify that the regulator with inline monitor function is fully open (100%).
17	NOTICE The regulator with in-line monitor function is fully open, when the pressure indicated on the intermediate set-point gauge is the same as the upstream pressure gauge.
18	Close the vent valve. Verify that the downstream pressure, after lock-up, does not exceed the closing pressure value.
19	NOTICE Check the set-point by referring to the pressure gauge located downstream.
20	Check with a leak foaming substance the tightness of all joints located between the shut-off valves. Very slowly open the downstream shut-off valve until the pipeline is completely filled.
21	NOTICE • If at the beginning of this operation the pressure in the pipeline is much lower than the set pressure, it will be advisable to partially open the valve in order to not exceed the set-point or the maximum flow rate of the system. • Check the set-point by referring to the pressure gauge located downstream.


1.10 - TECHNICAL CHARACTERISTICS/PERFORMANCE

The Cirval equipment is a regulator for medium and low pressure. The control system is balanced and guarantees a stable outlet pressure even when the inlet pressure varies. The main specifications of this regulator are:

Technical features	
Maximum allowable pressure	up to 125 psi
Ambient temperature range	-20°F to +150°F
Inlet gas temperature range	-4°F to +140°F
Inlet pressure range (bpu)	2 - 75 psi
Possible adjustment range (Wd)	7" W.C. - 12 psi
Minimum differential pressure	1.75 psi
Accuracy class AC	up to 10 (depending on operating conditions)
Shut-off pressure class (SG)	up to 20 (depending on operating conditions)
Orifice	• Cirval 200: 3/4" • Cirval 300: 1" 1/2"
Tubing Connections	• Cirval 200: 1" 1/4, 1" 1/2 and 2" NPT according to ANSI B1.20.1 • Cirval 300: 2" NPT according to ANSI B1.20.1, 2" S.125FF according to ANSI B16.5

Coefficients Cg and K1		
Model	Cirval 200	Cirval 300
Coefficient Cg	200	759
Coefficient K1	89	96

1.11 - COMMISSIONING/MAINTENANCE EQUIPMENT

Rf.	Type of equipment	Rf.	Type of equipment	Rf.	Type of equipment	Rf.	Type of equipment
A		E		I		O	
B		F		L		P	
C		G		M		Q	
D		H		N		R	